

Kanaltabell for båndet 7125-7425

Nr.	7 MHz raster		Nr.	28 MHz raster		Merknader		
1	7128	/	7289	1	7128	/	7289	
2	7135	/	7296					
3	7142	/	7303					
4	7149	/	7310					
5	7156	/	7317	2	7156	/	7317	
6	7163	/	7324					
7	7170	/	7331					
8	7177	/	7338					
9	7184	/	7345	3	7184	/	7345	
10	7191	/	7352					
11	7198	/	7359					
12	7205	/	7366					
13	7212	/	7373	4	7212	/	7373	
14	7219	/	7380					
15	7226	/	7387					
16	7233	/	7394					
17	7240	/	7401	5	7240	/	7401	
18	7247	/	7408					
19	7254	/	7415					
20	7261	/	7422					