

Kanaltabell for båndet 7425-7725

| Nr. | 7 MHz raster | | Nr. | 28 MHz raster | | Merknader |
|-----|--------------|------|-----|---------------|------|-----------|
| 1 | 7428 / | 7589 | 1 | 7428 / | 7589 | |
| 2 | 7435 / | 7596 | | | | |
| 3 | 7442 / | 7603 | | | | |
| 4 | 7449 / | 7610 | | | | |
| 5 | 7456 / | 7617 | 2 | 7456 / | 7617 | |
| 6 | 7463 / | 7624 | | | | |
| 7 | 7470 / | 7631 | | | | |
| 8 | 7477 / | 7638 | | | | |
| 9 | 7484 / | 7645 | 3 | 7484 / | 7645 | |
| 10 | 7491 / | 7652 | | | | |
| 11 | 7498 / | 7659 | | | | |
| 12 | 7505 / | 7666 | | | | |
| 13 | 7512 / | 7673 | 4 | 7512 / | 7673 | |
| 14 | 7519 / | 7680 | | | | |
| 15 | 7526 / | 7687 | | | | |
| 16 | 7533 / | 7694 | | | | |
| 17 | 7540 / | 7701 | 5 | 7540 / | 7701 | |
| 18 | 7547 / | 7708 | | | | |
| 19 | 7554 / | 7715 | | | | |
| 20 | 7561 / | 7722 | | | | |